


TOPSY 20000™

With Keyed Lock System

Operating Instructions


1



Ensure illustration is uppermost.

2


Insert the key **all the way** into the lock. (Do not turn the key.) This will automatically release the locking mechanism.



Important: Prior to installation or ballasting, it may be necessary to restrain the Plinth from spinning when removing the Hood. See note A.


3

With the key still in position, turn bin body anti-clockwise, and lift bin body over liner.




4

Remove the key at this stage.




5

Lift liner out of plinth, empty and place back into plinth. Ensure handles drop outside the liner.



6

Lift bin body over liner and lower to rest on plinth, turn bin body clockwise to lock.



PLEASE NOTE

- A** Glasdon recommends ALL TOPSY 2000 Litter Bins be ground fixed or ballasted to maximise the performance of the unique locking System.
- B** Prior to bolting the Plinth to the ground, rotate the complete unit until the litter apertures are in the preferred alignment.
- C** Regular cleaning is essential to maintain the pristine appearance of this quality product. All surfaces of the unit should be regularly cleaned with warm, soapy water and thoroughly rinsed. *This is important in maintaining both the outward appearance of the product and ensuring ease of operation.* Any damaged components should be replaced. Spares are available direct from Glasdon U.K. Ltd.

Glasdon U.K. Ltd. cannot be held responsible for claims arising from incorrect installation, unauthorised modification or misuse of the product.